QUIZBOT SHOW™

Instructions for setting the selectable options

Disconnect all cables and wires from the Quizbot Show controller and carefully remove the two screws securing the case.
Note the Dip Switch inside the unit. It looks something like the drawing in Fig 1. (The white block is the switch handle.)
Select the line on the table below that has the option combination you want. Set the switches to match the pattern on the line you chose.
You can use a small screwdriver or pen to move the switches.
Reassemble the case and secure the screws. Do not over-tighten the screws.



Fig. 1

Lights	Answer	Timer	Buzz-in		Dip Switch Pattern 1 2 3 4 5 6 7 8 9 10	Ref.
Blink	30 Sec	Beep	**Tone**			1
Blink	30 Sec	Beep	**Arcade**			2
Blink	30 Sec	Beep	**Siren**			3
Blink	30 Sec	Beep	**Whoop**			4
Blink	30 Sec	Song	**Tone**			5
Blink	30 Sec	Song	**Arcade**			6
Blink	30 Sec	Song	**Siren**			7
Blink	30 Sec	Song	**Whoop**			8
Blink	15 Sec	Beep	**Tone**			9
Blink	15 Sec	Beep	**Arcade**			10
Blink	15 Sec	Beep	**Siren**			11
Blink	15 Sec	Beep	**Whoop**			12
Blink	15 Sec	Song	**Tone**			13
Blink	15 Sec	Song	**Arcade**			14
Blink	15 Sec	Song	**Siren**			15
Blink	15 Sec	Song	**Whoop**			16
No Blink	30 Sec	Beep	**Tone**			17
No Blink	30 Sec	Beep	**Arcade**			18
No Blink	30 Sec	Beep	**Siren**			19
No Blink	30 Sec	Beep	**Whoop**			20
No Blink	30 Sec	Song	**Tone**			21
No Blink	30 Sec	Song	**Arcade**			22
No Blink	30 Sec	Song	**Siren**			23
No Blink	30 Sec	Song	**Whoop**			24
No Blink	15 Sec	Beep	**Tone**			25
No Blink	15 Sec	Beep	**Arcade**			26
No Blink	15 Sec	Beep	**Siren**			27
No Blink	15 Sec	Beep	**Whoop**			28
No Blink	15 Sec	Song	**Tone**			29
No Blink	15 Sec	Song	**Arcade**			30
No Blink	15 Sec	Song	**Siren**			31
No Blink	15 Sec	Song	**Whoop**			32

If you need help or have questions call Alan at Bredon Electronics 817-657-8489 anytime.